



© 2021 Pro-Stitcher Lite


Open a Design

- **File Tab>Design>Open**
- 1-PS Designs/Blocks/Block of Lines
- Create an Area
- Move your machine to the top left corner of where you want to create your area.
- Select **Area tab>2 corner** from the ribbon.
- Move your machine down to the right, and select **2 Corner** again.
- Select the **Modify tab>Crop**




In the sidebar, you have three options for cropping: **Inside** & **Outside** and **Start End**.

- **Outside** Crop




Inside Crop:



- You can close your edges or leave them open, depending on how you want the edge of your cropped design to be finished.

To move start and end points, select **Pro-Stitcher tab>New Start & End**. In the sidebar, adjust the start and end points with the arrows in the sidebar.

- **Start End** Crop:



- After cropping your design, **Baseline**, set up your frame space, and then stitch your design.