


# How to Register PS Catalog

**START HERE IF YOU ALREADY HAVE PS DESIGNER INSTALLED ON YOUR COMPUTER.**


**If you do not have PS Designer installed on your computer,  
skip ahead to page 3, "How to Install PS Catalog".**

## Option 1: Register PS Catalog on a Computer or Tablet with Internet Connection


1. Locate the **PS Software icon** on the Desktop. Double-click on the icon to launch the software.
2. When the PS Designer landing page appears, click on the **X** in the top right corner of the screen to close the window.




3. The View windowpane on the lower right side of the screen will have a Purchases tab with a shopping cart icon. Click on the **shopping cart** to open the Purchase menu and display the available Pro-Stitcher Software modules.



4. Click the box with **3 dots** on the right side of the Pro-Stitcher Catalog bar. A drop-down menu will load.
5. Select **Activate**.




5. The Welcome screen will load.
6. Fill in all of the required boxes. Fill in the serial number provided in the purchase confirmation email. Remember the serial number is case sensitive (turn on your caps lock) and include the dashes.




The screenshot shows a 'Welcome' window for 'Pro-Stitcher Catalog'. It contains a registration form with the following fields: \*First name (filled with 'Ima'), \*Last name (filled with 'Quilter'), Company name, \*Address, \*City, \*State (dropdown menu showing 'UTAH'), \*Zip/Postal, \*Country (dropdown menu showing 'US'), Work phone, \*Home phone, \*Email address (filled with 'ie. account@provider.com'), \*Serial Number (filled with 'XNWN-HK7N-437F-JCXH-RX3Y'), Reg. Number, and Activation Code. A red arrow points to the 'Register now' button at the bottom right. A red circle highlights the 'Register now' button. A red line of text at the bottom reads 'Your personal information will not be sold or used'. A small note at the bottom left says '(\*)Required'.

7. **The Register Now** button becomes active once all the fields are correctly populated. Click **Register Now** to register your software.

 **NOTE:** A registration number is already populated, and since the device is connected to the internet, there is no need enter an activation number. It will populate after the **Register Now** button is clicked.

8. A message will load, prompting you to restart the Application. Click **OK**.




9. From the Pro-Stitcher Software window select the **File** tab, then Exit from the drop-down menu.
10. Registration is now complete.

# How to Install PS Catalog


**Follow these instructions ONLY if you do not have PS Designer installed on your computer.**

On a computer with internet access, open the purchase confirmation email received after purchasing Pro-Stitcher Catalog. Click on the **link** in the Download column titled “Pro-Stitcher Catalog.” The software will save to the Downloads folder of the computer’s C: drive.




1. Open **Windows File Explorer** and select the **Downloads** folder.


- To install on the computer, double-click on the **PSDSetup file** to launch the InstallShield Wizard.
- To install on a tablet without internet connection, copy and paste the file to a USB drive. Take the drive to your tablet, insert in the USB port and proceed with the installation instructions.

 **NOTE:** Windows may generate a message asking “Do you want to allow this app to make changes to your device?” Select Yes to proceed with installation.


2. The Pro-Stitcher Software – InstallShield Wizard will launch. Select **Next**.




3. Click “I accept the terms in the license agreement” then click **Next**.



4. On the next screen, click **Install**. The InstallShield Wizard will run the installation.




5. Click **Finish** to complete the installation.



## Option 2: Register PS Catalog as a Stand-Alone Component on a Computer or Tablet with Internet Connection

1. Locate the **PS Software icon** on your Desktop. Double-click on the icon to launch the software.
2. The Welcome screen will load.
3. Select **Pro-Stitcher Catalog** from the drop-down menu.



4. Fill in all of the required boxes. Fill in the serial number received in the email confirming your purchase. Remember that the serial number is case sensitive (turn on caps lock) and include the dashes.

Welcome

Please enter your registration information for the following software  
Pro-Stitcher Catalog

You must complete this form in order to complete the installation process

Registration information

\*First name: lma \*Last name: Quilter

Company name:

\*Address:

\*City: \*Zip/Postal:

\*State: UTAH \*Country: US

Work phone:

\*Home phone:

\*Email address: ie. account@provider.com

\*Serial Number:

Reg. Number: XNWN-HK7N-437F-JCXH-RX3Y


Activation Code:

Your personal information will not be sold or used


(\*)Required

Register now

5. The **Register Now** button becomes active once all the fields are correctly populated. Click **Register Now** to register your software.

 **NOTE:** A registration number is already populated, and since the device is connected to the internet, there is no need enter an activation number. It will populate after the **Register Now** button is clicked.

6. A message will load prompting you to restart the Application. Click **OK**.



7. Select the **File** tab on the Pro-Stitcher Software Window, then Exit from the drop-down menu.
8. Installation is now complete.

### Option 3: Register PS Catalog on a Computer or Tablet without an Internet Connection


If registering on a device with no internet connection (such as a Pro-Stitcher tablet) follow the procedures outlined above in Register Your Software Option 1 through Step 5, when you get to the Welcome screen. Proceed with the following steps to obtain an activation number:

1. Fill in all the required boxes. Fill in the serial number received in the purchase confirmation email. Remember the serial number is case sensitive (turn on caps lock) and include the dashes.
2. Write down the Registration Number (this number auto-populates with a different number each time the software is launched until it is registered.)
3. DO NOT TURN OFF YOUR TABLET.
4. Go to a computer that has internet connection.
  - Open a web browser, and go to <http://www.esoftwareondemand.com/ProductRegistration.aspx>
5. Fill in all of the boxes with asterisks by them. Fill in the serial number you received in the purchase confirmation email. Remember the serial number is case sensitive (turn on caps lock) and include the dashes.
6. Fill in the Validation Code with the Registration Number from step 2. Remember the Validation Code is case sensitive (turn on your caps lock) and include the dashes.

*Required Information	
* First Name	Required Field
Middle Initial	
* Last Name	Required Field
Company Name	
* Address 1	Required Field
Address 2	
* City	Required Field
* State	SELECT <small>If outside the USA, Enter a value for Province/Territory</small>
* Province/Territory	
* Zip	Required Field
* Country	USA
* Phone Number	Required Field
Fax Number	
* Email Address	Required Field
* Serial Number:	Required Field
* Validation Code	Required Field
<b>Activation Code:</b>	
Submit	

7. Click on the **Submit** button at the bottom of the screen.
8. An Activation Code will populate in the gold box at the bottom.
9. Write down the Activation Code.
10. Go back to the tablet and enter the Activation code in the appropriate box. Remember the Activations Code is case sensitive (turn on your caps lock) and include the dashes.

11. The **Register Now** button becomes active once all the fields are correctly populated. Click to register the software.



Welcome

Please enter your registration information for the following software  
Pro-Stitcher Catalog

You must complete this form in order to complete the installation process

Registration information

\*First name: Ima \*Last name: Quilter

Company name:

\*Address:

\*City: \*Zip/Postal:

\*State: UTAH \*Country: US

Work phone:

\*Home phone:

\*Email address: ie. account@provider.com

\*Serial Number:

Reg. Number: XNWN-HK7N-437F-JCXH-RX3Y


Activation Code:

Your personal information will not be sold or used

(\*)Required

Register now

12. A message will load prompting you to restart the Application. Click **OK**.



13. The software will open. On the Pro-Stitcher Software screen, select the **File** tab, then Exit from the drop-down menu.
14. Installation is now complete.
15. On your desktop, the PS Software icon will be added.