# **Pro-Stitcher<sup>®</sup> or Pro-Stitcher Lite<sup>™</sup> Simulation** Installation Instructions

You can create a simulation version of the Pro-Stitcher software which enables you to use it in simulation mode on any computer running Microsoft Windows 7 or later. Simulation also runs on the Pro-Stitcher tablet when not attached to the guilting machine. Using simulation enables you to take the tablet or a notebook computer to Pro-Stitcher training and use the software functions even though the computer isn't attached to a quilting machine. If running the simulation mode on the Pro-Stitcher tablet, you may switch between simulation mode and regular mode. However, when running Pro-Stitcher on a standalone Windows computer, it only runs in simulation mode.

#### **PC Requirements**

Windows 10 or later Net framework 4.6.2 or later MS Visual C++ 2015 or later Open GL 3.0 or later

#### Downloading the Pro-Stitcher Software

- 1. On a computer connected to the internet, navigate to the Pro-Stitcher website: www. ProStitcher.com.
- 2. Select **Pro-Stitcher** from the menu at the top of the screen, and then select **Software** from the drop-down menu.



3. Under the Premium tab, click on the + next to Latest Version.

Pro-Stitch	er STUDIO				
	Home	Pro-Stitcher 🗸	Pro-Stitcher Lite 🗸	Pro-Stitcher Designer 🗸	
Software \	/ersions ar	nd Dowi	nloads		
Premium	Premium - BETA	Lite	Lite - BETA	Standard	
Latest Pro-Sti	tcher Premium F	Releases			
This Pro-Stitcher softwar and carriage.	e is specific to the Pro-Stitc	her tablet and carria	age you use. Be sure to s	elect the correct version	
Important!					
<ul> <li>Make sure to restar properly.</li> </ul>	t both your tablet and your	machine after comp	oleting the update proce	ss or your Pro-Stitcher	
Make sure you are on the Quilt tab under Pro-Stitcher to find Run button.					
		🎒 TABLET AND	CARRIAGE CHARTS		
PS Premium: Latest Ver	rsion (21.07.0537)				
+ PS Premium: Version 19	9.07.0506				

 From the software choices, select your corresponding software, Pro-Stitcher Premium or Pro-Stitcher Lite. Click Download.

Pro-Stitcl	er STUDIO	Pro-Stitcher ~	Pro-Stitcher Lite 🗸	Pro-Stitcher Designer 🗸	Pro-Stitcher Catalog ~
oftware '	Versions an	d Dowr	nloads	Ŭ	, i i i i i i i i i i i i i i i i i i i
Premium	Premium - BETA	Lite	Lite - BETA	Standard	Classic
.atest Pro-Sti	tcher Premium R	eleases			
his Pro-Stitcher softwa	re is specific to the Pro-Stitch	er tablet and carria	ge you use. Be sure to	select the correct versio	n based upon your tablet
1d carriage.					
Important!					
Make sure to resta	rt both your tablet and your i	naching after compl	loting the undate pro-	core or your Dro Stitchor r	nau not function
<ul> <li>make sure to resta properly.</li> </ul>	it both your tablet and your i	nachine arter comp	tering the update pro-	cess of your Pro-Sutcher I	nay not runction
<ul> <li>Make sure you are</li> </ul>	on the Quilt tab under Pro-St	itcher to find Run b	utton.		
		TABLET AND	CARRIAGE CHARTS		
DS Dramium: Latast Va	mion (21.07.0527)				
All Brands October 08, 2021					
21.07.0537					
Pro-Stitc	her <sup>.</sup>				
PREMIUM					
DOWNLOAD					
DOWNEDAD					

 The zip file saves to the **Downloads** folder on the computer. Open your Downloads folder. Select the PSPUpdate.{Version#} folder, right-click and select **Extract All** to unzip the files.



#### Run Pro-Stitcher Pre-Install

- NOTE: The PS Pre-Installer updates your computer with required support software and must be run prior to updating Pro-Stitcher software, including Pro-Stitcher Simulator.
- 1. Locate the unzipped file in your Downloads folder. To run the file, double click to open the folder.

This PC > Downloads				
	Name			
	PsPUpdate			
s	PsPUpdate.19.07.0506_H			

 Double click on PsPreInstall.[Version#] to run.

This PC > Downloads > PsPUpdate.19.07.0506_H				
25	Name PsPreInstall.18.02.0012 PsPOpdate.19.07.0506_H			

3. Select **Start** when this screen appears.

ProStitcher	-		$\times$
Welcome to the Pro-Stitcher Premium PreIn	ıstall	upda	ter.
Version: 18.02.0012			
Press "Start" to update PreInstall, or "Cancel" to exit.			
Repair	Start	Car	ncel
Welcome			

NOTE: If prompted, follow steps 4 through 14. If your computer is up to date, you will receive a message that the most up-to-date files are already installed. If so, select OK and proceed to the next section: To Install Pro-Stitcher Simulator Onto Your Computer.

November 2023

4. Follow the prompts in the updater when prompted.



 If your computer is up to date, you will receive messages that the files are installed. Select **OK** on the pop-up windows, and then select **Close** in the updater window.

ProStitcher	—		×
Installation completed.			
F			
		Clo	ose
Finished			

6. Go to page 5 and proceed with Install Pro-Stitcher Simulator Onto Your Computer.

#### If prompted, follow the steps below.

7. When the Visual C++ Redistributable installer appears, select the "I agree..." box and then select **Install.** 



8. Select Close.



9. Wait for up to several minutes for the next step to finish.

Extracting files	×
	Cancel

- 10. Mark the "I have read..." box and select **Install** to begin installing the .NET 4.6.1 Framework files required for Pro-Stitcher.
  - IMPORTANT: If the .NET installer indicates that you have a more current version, close the message box and continue to follow the on-screen instructions to complete Pro-Stitcher installation. Reboot the computer when it is finished.



11. Wait until the installation finishes. This may take several minutes.

<b>J</b>	Microsoft .NET 2015	- 🗆 🗙
<b>.NET Framework 4.6</b> Please wait while t	•1 Setup he .NET Framework is being installed.	.NET
File security verific	ation:	
All files were verifie	ed successfully.	
Installation progre	551	<u> </u>
		Cancel

12. If you receive a message asking you to close some programs, select **No**.



13. Press **Finish** when the installation is complete.



14. When prompted to restart the computer, select **Restart Later**.

Microsoft .NET 2015				
You must restart your computer to complete the installation. If you choose Restart Later, applications dependent on .NET Framework may stop working.				
Restart Now Restart Later				

15. When you see the Installation Completed message, press the **Close** button.



- 16. Upon completion, the Pro-Stitcher Pre-Install software will automatically try to start up, but you will receive an error message due to the .NET software installation not being fully complete. Close the message, which returns you to the Windows desktop.
- 17. Reboot the computer to complete the installation process.

## Install Pro-Stitcher Simulator Onto Your Computer

 Locate and run PsPUpdate.[Version#].exe by double clicking the file on your computer. If a pop-up appears asking if you want to allow the app to make changes to your device, select **Yes**.



2. Select Start when this screen appears.

🗑 Handi Quilter	_		$\times$
Welcome to the Pro-Stitcher Premiu	ım u	pdat	er.
Installed Version: 00.05.0106 Update to version: 19.07.0506			
Press "Start" to update Pro-Stitcher, or "Cancel" to exit.			
Repair	Start	Can	icel
Welcome			

3. Select **Confirm** when this screen appears.



4. Installation can take a few minutes. Select **Close** when indicated.

November 2023

### Copying Designs from Pro-Stitcher Tablet to PC or Laptop

IMPORTANT: Installing Pro-Stitcher on a PC, laptop, or non-Pro-Stitcher tablet will not copy the Designs file folder. This will need to be done manually.

To copy the Designs folder from the Pro-Stitcher tablet, insert a USB flash drive into the Pro-Stitcher tablet's USB port.

Access Windows File Explorer and navigate to C:\Designs. Select C:\Designs and drag or copy and paste the folder to the USB Flash drive.

Once the Designs folder has successfully copied to the USB flash drive, remove the flash drive from the Pro-Stitcher tablet and insert it in the USB port on the PC, laptop, or tablet.

Access Windows File Explorer. Locate the Designs folder on the USB flash drive. Drag or copy and paste the folder from the USB flash drive to the main directory C:\.

IMPORTANT: Once Pro-Stitcher Simulation is installed, the display settings may need to be adjusted for Pro-Stitcher Simulation to work correctly. Select the Settings tab. Select Display. Maximize the window for Pro-Stitcher. In the Monitor box, measure the monitor and enter the correct dimensions.

6