






- Select the **Home** tab. 
- From the ribbon, select **New**. 
- From the Sidebar, click on the **Designs** tab in the lower window. 
- From the bottom half of the window, click on a design and drag it onto the design page.






To demonstrate, we opened **Block 16.hqv**.

- In the upper window, click on **Transform**



*Adjust your width and height so it will print to the size desired for your project. Make sure that **Maintain Aspect Ratio** is checked if you want to keep your design proportional as you make changes. Click **Apply** when you have finished making your changes.*

- Select the **Home** tab. 
- From the ribbon, click on **Print Preview**. 
- A **Print Preview** window will open. You can verify that the design looks as you'd like it, then click on the print button when ready.



- A print dialog box will open from your computer. Select your desired printer, then click on print.
- You now have a stencil!