

Three ways move your start or end point.

- Select Pro-Stitcher Tab.



- From the ribbon, select New Start & End.



- In the sidebar, there are now 3 sets of arrows for moving your start and end points.
- The top set moves the point 1 stitch at a time.
- The middle set moves the point 1 design point at a time.
- The bottom set moves the point from one long jump to the next.

